

Version: 8.0.2

Last update: March 2015

neoStampa

Index

1. Introduction	4
1.1 Starting the wizard 8	4
2. Print configuration	6
2.1 Printer selection	6
2.2 Configuration of the spectrophotometer	7
2.3 Action selection	7
2.4 Check printer and/or profile consistency	8
3. Print parameters	11
3.1 Quality	11
3.2 Color mode	11
3.2.1 Set color order	11
3.2.2 Double ink	12
3.2.3 Mask	13
3.3 Dithering	15
3.3.1 Raster settings	15
4. Absolute ink limit, Single ink limit and Linearization	17
4.1 Step 1 - Ink limit	17
4.2 Step 2 - Single ink cut	19
4.2.1 Without light inks	21
4.3 Step 3 - Linearization	22
5. hueman v2 - Black generation	26
5.1 Method	26
5.2 Patch file	27
5.3 Add function	28
5.4 Print	28
5.5 Rich black	28
6. Advanced settings	30
6.1 Revision	30
6.2 Profiling mode	27
6.3 Balance	31
6.4 Black start	31
6.5 Body (light)	31

	6.6 Body (dark)	32
	6.7 Ink limit method	32
	6.8 BlackOptimizer	32
	6.9 Shadow dot gain	32
7. Prir	nter profiling	34
	7.1 Select target file	34
	7.2 Print	35
	7.3 Measure	35
	7.4 Import data	36
	7.5 Export data	36
	7.6 Smoothing amount	36
	7.7 Generating the profile	36
	7.8 Add profile to list	37
	7.9 Gamut and quality view	37
8. Wo	rkflow	38
	8.1 Test print	39
	8.2 Comments	40
	8.3 Scheme Backup	40
	8.4 Finish	41

1/ Introduction

The main purpose of the Wizard 8 is to create new scheme calibrations. Those are used by **neoStampa 8** to print under the same conditions on the desired media. Following through the Wizard 8 you can print different kind of test charts, in order to control and set ink amounts, linearization curves and maximum ink limits, as well as printing an ICC target and create an ICC printer profile.

The most important difference from **neoStampa 7** calibration wizard is that this new version offers a better control of the ink limit -and therefore better dark and light transitions-, and in some cases larger qamut.

This Wizard 8 also offers the option to check existing calibrations, without having to go through the whole process of measurements.


In this User Manual you will find descriptions of the options that the Calibration Wizard offers, and extensive explanations as of various processes and aspects involved in this process.

1.1 Starting the Wizard

Access the Calibration Wizard 8 from the **Printer Scheme Manager,** in neoStampa's 8 upper bar on the main window.



The Calibration wizard button is at the bottom left corner of the Printer scheme manager:




The program opens at clicking on the Wizard button:



2/ Print Configuration

In the first window of the Wizard you are required to introduce the most basic information for the calibration.




The buttons at the bottom -apart from Configure- allow to move through the different windows of the Wizard, and to Exit the Calibration, whether saving it or not.



2.1 Printer selection


In the upper part of the window are the settings of the printer you want to make the calibration with.



Hitting the square button with three dots will allow to add a printer to the list of printers that you already have.

2.2 Configuration of the spectrophotometer

At the bottom of the window, as we have seen, there is the **Configure** button, which will open the window to set the device you are going to use for measurements:




Depending on the device you use, the options for Transparency, Zebra ruler or UV filter will be activated or not.

The **Color management** option in this window allows to select whether to work with the new neoStampa 8 profiler, -set as recommended-or the old neoStampa 7 one.

2.3 Action selection

There are three options in the Action selection field. The two first ones are described following.

The first is to **Start a new calibration**, in which you need to fill in the information as for Media name, Ink type and Quality. **Inèdit** recommends to include all this information, as your scheme will be easily identified. Anyway, the name of the scheme can be changed later on.



Legacy mode, when activated, will use the older profiling engine of neoStampa 7, and therefore a different process. Please refer to the Calibration Wizard 7 manual to know how to use it.

The second option is to **Continue and existing calibration.** Just open the drop-down list and choose the one you need, and clicking on the checkbox, allows to see the already completed calibrations:



2.4 Check printer and/or profile consistency


This function is new in respect to the Calibration wizard 7. This is a very useful tool to check if the profiles that you have already generated still keep the same quality. However, If you need to change inks, or media, this re-profiling is not the thing to do as you should make a whole new calibration.

Search for the scheme in the drop-down list, and hit **Next**, on the lower bar. You will access the last profiling window of the calibration:


Check printer consistency and/or re-profile

< Previous Next > Configure Exit
🔐 neoStampa 8
Compare measurements
This tool allows you to measure the control strips and compare against the result of the initial measurement when profiling
RGBReprofileChart750_v3_j1.ti2 ▼ Print Print
RGB, 152 patches
Compare against measurements from initial profile or a previous measurement: Cotton Reactive 720 x 720 141202.icm
Cotton_Reactive_720 x 720_141202.icm ▼ + RGB, 738 patches
Results: dE76 dE2000 Average
Maximum - White - Black - View all results Export results
Re-Profiling
If the obtained DeltaE results are larger than desired you can generate a new profile. This tool re-profiles your previous ICC profile using a combination of the initial measurements and the measurements from the control strip. For the best result it is usually recommended to print a normal ICC target with 1500 patches or more.
Generate
Embed the new profile into scheme:
None +
Cotton_Reactive_720 x720_141202
< Previous Finish Configure Exit

Since this process is just a check, the profile that will be generated is based on about 150 patches. Choose the type of profile, according to the reading device:




Proceed now to Print the target and measure it. As in all Prints in the Wizard, you will be able to configure it before:




When the reading is done, you will get the compared DeltaE results.




And if you wish to see all the compared colors, click on the **View all results** ... button:



If the obtained deltaE are larger than desired, you can now proceed to generate a new profile, pressing the **Generate** button, and once you have it, **embed** the new profile into the scheme:




Finally press **Finish**, and a last dialog will pop-up, where you can give a new name to the scheme:



3/ Print Parameters

Establish color specifications such as for Color mode, Print quality and Dithering in the second window of the Wizard.



3.1 Quality

Quality is usually printer dependent and is provided by the driver specifications of each printer.


In the "Advanced" button next to it, you can see and change -if necessary- printer specific parameters, such as single or bi-directional printing, number of passes, etc. Also here, the content of this window is driver specific.

3.2 Color mode

The **Color mode** is selected from a drop-down list. The available selection depends on the printer specifications. For standard plotters from main companies such as Epson, Canon, Hp, etc., some presets will appear on the list, where inkset and order are set automatically. Press the three dots button to specify these parameters if the plotter has been modified by any third party, or for direct printing models.

3.2.1 Set color Order

Press the three-dots button on the right of Color mode to set the color order for the selected mode. Apart from that, you can also set other parameters such as multiple inks or special colors from the window that pops up:




Print: In case you are not sure what ink order is loaded in you printer, you can print out a chart showing a number for each printed base color. Certain printers have a special ink order coming from the driver documentation (e.g. Epson, Mutoh). It is recommended to print out this chart if you are not sure of the order or if you encounter strange color effects during the calibration process (e.g. Black prints Cyan).

Set color order: On the left side of the window, set the inks in use according to your machine specifications or to the previously printed mini chart. There are many inks available in neoStampa RIP, and make sure you select the correct ones. Be careful when selecting Gray and Light Gray, as the latter can only be used if Gray is present. Gray is sometimes called Light Black by certain ink suppliers, and Light Gray would be Light Light Black for those too.

3.2.2 Double Ink

You can place the same ink into different slots multiple times. If you do so, the *Double Ink* button is activated and lets you specify the behavior of those inks.



Channel: Toggle between the multiple inks. For each ink you can set an individual curve behavior. The use of multiple inks is basically to make the total color get darker or more saturated. Setting different behaviors for each channel enables special effects, such as minimizing dithering in lighter areas. A consideration in this software-based approach of multiple inks lays upon the fact that certain printheads are more used than others. Finally, the combination of multiple inks, including all the set parameters, are linearized as one new ink.


We recommend that at least one channel should be linear and that you should NOT change the parameters after you have linearized the combo.

View curve: It presents the behavior of the curve for the selected ink. Make sure that it looks smooth, if you want to obtain homogeneous results. You can change the Start, Body and End by increasing or decreasing the values below.

- Start: This value defines where the ink starts. 25 means that the selected channel will not print below 25% of original coverage.
- Body: This value defines where the ink starts. You can try different values to evaluate which
 ones are the most suited to deliver a smooth shape. 75 is a good value if Start s at 25% and
 End at 100%.
- End: This value should usually be set at 100, since the idea is to get darker color. Note, however, that in some cases you might have too much ink, and you may have to reduce it in the ink cut procedure, which will be explained further on in this manual.

3.2.3 Mask

If you have special inks loaded, such as a penetration liquid, dilution ink, mask or white inks, you can set parameters for this in the Mask channel settings window. The Mask ... button becomes available when you select one of the following inks: Mask, White (background), Dilution ink.



Following you can find explanations for each of the options available in this window:

Get from alpha channel: As the name says, the image to print requires an additional Alpha channel added to the image, e.g. manually created in Photoshop. The ink then uses the channel information to print the content. Depending on the printer, the ink will be printed in a separate pass or simultaneously with the other inks.

Full mask: neoStampa will create a flat color underneath the image whenever a pixel is present (with Photoshop: always; with Illustrator or CorelDraw: whenever an object contains a color information, such as white). Note that the full mask generation is only done if the image is in Grayscale, RGB, CMYK or LAB, but not with multichannel files. So, when printing linearization targets the full mask will not print.

Shadow mask: neoStampa will create an intelligent grayscale mask under the image information according to its color intensity and color darkness. Usually, this mode is used when printing white ink, e.g. for T-shirt printing. Note that the Shadow mask generation is only done if the image is in Grayscale, RGB, CMYK or LAB, but not with multichannel files. So, when printing linearization targets the shadow mask will not print, but it will be generated when printing the ICC target.

Fill ink: This method is usually used for penetration liquid or for a fill-up ink, such as dilution inks or similar. The penetration liquid is provided by several ink suppliers with the idea of helping inks in lower percentages to penetrate through the textile media. The fill ink method needs specifying an Intensity and Minimal value explained underneath.

Put ink in white pixels: Usually white pixels do not require a penetration liquid or dilution ink-since the area is not printed anyway-, which results in ink savings. In certain printing environments (e.g. carpet printing using Zimmer ChromoJET800) this check-box helps to create a blocking area around the colored image using dilution ink to prevent colors from bleeding into non-printed areas. Note that "white pixels" refer to an image information with an object containing no color (with Photoshop: always; with Illustrator or CorelDraw: whenever an object is found containing a white color).

Intensity: The Fill ink method will fill up with dilution ink, whenever this specified value is not reached by the absolute amount of other inks in the ink set. So, when you print 10% Cyan+25%Magenta+30%Gray, the absolute amount of ink will be 65%. In this case, neoStampa will automatically add a 35% of dilution ink for better penetration.

Minimum value: Specifying a minimum value for the Fill ink method adds a certain amount to an absolute ink amount in any case. Scenario: If you set intensity to 100% and the Minimum value to 10% and the absolute amount of ink of 25% Cyan+35% Magenta+ 75% Gray exceeds the 100% of specified Intensity, then neoStampa will add another 10% on top of it. This will help the ink to penetrate even more, but can also cause a certain amount of bleeding if applied too much. This value should be used with care.

3.3 Dithering

neoStampa 8 provides different raster methods. Two of them are the most common to use:

Smooth Stochastic (default):


This raster is a matrix-based method that places the dot matrix in the most homogeneous way, and it is recommended for all types of inkjet printers. It has, however, some drawbacks, specially with n-level printheads, as the nozzle can suffer from stress.

Diffusion v2


This raster is based on a Smooth Stochastic matrix but adds some error diffusion to the final raster. In terms of performance, this method puts holes into the regular matrix in order to give time for relaxation to the nozzle, in order to prevent the previously mentioned stress factor. The raster method is homogeneous as the first one, but since certain dots are removed, it might be that the dot placement does not look as "perfect" as with the Smooth Stochastic.

3.3.1 Raster Settings

The option Dithering unfolds a drop-down list:



The button with three dots on the right of the list allows to set different types of dots, which we explain following:



Disable large dot: If you have a delicate media that cannot pick up a lot of ink, disabling the largest dot (available with 2bit / 3 or more level printheads only!) can help. It can also help if the printhead has problems firing the large dot, but this is quite a rare scenario. As the name says, the largest dot will not be produced during rastering. We recommend however not to use this function as reducing ink in the perchannel ink cut provides more control.

Disable small dot: In some printing environment using certain printheads, the small dot never reaches the media since a combination of a small dot with high printing carrier movement speed, and/or electrostatic charge (e.g. using polyester fibre), deviates the dot so much that it is literally blown away. This can cause a lot of residual ink in the environment ,and the dust is placed anywhere, an effect that is certainly not wanted. Using this function switches off the usage of the smallest dots (available with 2bit/3 or more level printheads only!).

Only for black ink: If this box is selected in combination with "Disable small dot", then the smallest dot is only omitted in the Black channel(s).

Smoothness: This value becomes available when working with Diffusion v2 raster method in combination with an n-Bit / n-Level printhead. The smoothness defines the amount of error introduced to the matrix raster to avoid stress from the nozzles when firing full-time (mentioned in Dithering Part 1). A smoothness of 10 means that Diffusion v2 does not have any error diffusion (=Smooth Stochastic). By decreasing this value, dots are removed from the regular matrix and the n-Levels of variable drop technology are diffused into each other. A value of 6-9 delivers a good balance between quality and stress-reduction to printheads with variable dot technology. If you go lower than this value, there can be too much noise in the result and the print-out will go grainy. We recommend a value of 7 if you encounter such a firing stress problem. Note that changing to Diffusion v2 or changing the amount of Smoothness requires re-linearizing the printing conditions.


Dot multiplier: This value must be left at "1". We recommend NOT to change it.

4/Absolute Ink Limit, Single Ink Limit and Linearization


Once we have set up the different printing parameters, now it is time to start printing Step one of the calibration process. To complete this window of the Wizard there are three very important steps that need to be done, and they need to follow an order, always from top to bottom:

4.1 Step 1 - Ink Limit


In Ink Limit you are able to print up to a 300% of ink, to find the best absolute ink limit for your media on the test file.




Test file print to cut the absolute ink limit:




Before the actual print, a window opens with a preview of the charts, where you can adjust some parameters (ink channel, print direction, position, orientation and page setup):



The **Extra** option allows for a calculation of different inks together. The chart for this option differs from the other three ones:



To evaluate the test charts in textile media, make sure that it is steamed and washed before. Proceed to cut the inks entering the percentage shown below the first patches that show bleeding. Enter the value in the lnk limit text box.




For some other medias like paper, cutting inks criteria is different. In those, it should be entered the maximum percentage of ink before any irregularities -blurred, stripped, matte, wet print- appear.

4.2 Step 2 - Single Ink Cut


In Single Ink Cut you are able to cut single ink limit. Therefore you need to print a CMYK plus light inks test chart, with gradient 0%-100%. Ink cut limit just for the main inks, no lights, as shown in screenshot below (Channel/color).



Test file print to cut the single ink limit:




Once again, before the actual print and measurement, a window opens with a preview of the chart, where you can adjust parameters (ink channel, print direction, position, orientation, page setup): Linearization for full ink set, as seen in screenshot below:




When the above parameters are set, press **Ok** to print the test file. Once the print is ready -washed and dried or vaporized- proceed with the Measurement. Press the **Measure** button and connect the spectrophotometer. Follow the instructions for the specific device you are working with.


Notice that the **Calibration Wizard 8** offers the possibility to get 3 measurements for each print. This is useful when for example the media is rough, and we want to get much precise results. The Wizard will produce average values from the 2 or 3 measurements.




Notice also that the data for this measurements -and of each reading- can be **Exported**, with the bottom left button on the window, and, if necessary, they can also be **Imported**.




When you finish the reading, the Densities and Ink cut dialog will pop-up. The Wizard will perform an automatic ink cut, based on the values obtained. The new values are based on 100% of ink:



In **Light inks transition** you can pre-set the best ink transition.




Below the Light inks preset, the **Advanced** button will take to another window where more settings can be applied for the light inks. Only very expert technicians should change any of them:




4.2.1 Without Light inks


If your calibration is done without Light Inks, then step 3 can be avoided if none of the inks are cut at less than 60%.



When the inks are cut at a 60% or more, an option at the bottom right of the window appears.




Ticking this option, the measurements will be used and no other test charts will need to be printed, as the densities performance is already done:



4.3 Step 3 - Linearization


In Linearization, you are able to see the performance of CMYK ink set with light ink set in post-linearization curves. Therefore, you need to print a CMYK test chart with gradient of 0%-100%. Even without using light inks, you need to measure the Linearization. If you made ink cut in step 2, forward to print in step 3. If you made no changes, simply measure the printout from step 2.




Print Test file:



For the third time, the window with the chart preview and adjustments options pops-up:




After printing the test file, proceed to connect the spectrophotometer, as you did before. Then start reading the lines according to given specifications:



When you finish the reading, the Linearization performance will pop-up. The Wizard will make an automatic ink cut, based on the values obtained:




Clicking on the **Densities** button you will see the density values and the automatic ink cut calculation results. You can view all the curves together, or one by one:



The **Linearization** button shows the response curves window. We can make some adjustments so as to improve the result, if certain tones aren't as expected:

It is possible to modify graphically any of the color channels adding new points, by pressing on the line in a zone where there is no point, or modify the position of a point by pressing on it and displacing it onto a new position.



Input and Output values of each curve can also be modified manually, from the fields on the right.


The option **Reset Ink** erase all the points of the selected curve, which implies that no linearization will be made.

The button **Copy to all** allows copying the reference points of a curve to all the other ones.

In case few points are entered, the option **Smooth** can be selected so that the resulting curve is smooth and doesn't have rough changes in tonality adjustments.

5/ hueman V2 - Black Generation

In this new window you get to the part to define the Black generation of your printer's calibration. This process allows to determine which combination of inks provide the best black, as well as it prevents dithering of the black ink in the light areas, in case you don't have any gray ink in combination.



5.1 Method

hueman v2 Black generation provides 3 methods to generate the black ink:

• Default (Black only):

This method is recommended if you have a very good, strong black ink in your printer and if you also have a gray ink (=light black) that prevents dithering from the black ink in light areas. In this case the black generation will be black only.

Default (Black only): - consumption of inks - metamerism + dithering + stability on PostProcess

• Black Addition:

This method is recommended if a combination of inks is better than your pure black ink only, and if you also have a gray ink (=light black) in the printer to prevent dithering from the black in light areas. Here, the black generation will add the defined values of the additional inks to improve the overall darkness of the result. You can use the "Print.." button to determine whether a combination of colors including black is better than the black ink only.

Black Addition:

- consumption of inks
- -/+ metamerism
- dithering
- -/+ stability on PostProcess

• Gray Component Replacement (GCR):

This method is recommended if a combination of inks is better than your pure black ink and if you don't have a gray ink (=light black) in your printer. With this method CW8 will replace light areas of black with a combination of CMY inks, to visually minimize the dithering from the black ink. Be aware that such a GCR can be critical since the light fastness of C, M and Y are not always the same and that after a certain time one of the inks might fade faster than others resulting in a non-neutral behavior of gray areas (e.g. outdoor flag printing).

Gray Component Replacement (GCR):

- consumption of inks
- -/+ metamerism
- dithering
- stability on PostProcess

5.2 Patch file

In order to evaluate whether a combination of inks is better than your pure black ink, you can use the "Print.." button to print out a chart for visual analysis. You can select one of the charts in the list. For most printers, the BlackAdd_CMYK.psd (or the smaller A4-sheet-fitting BlackAdd_cmyk_A4.psd) will be enough. If you have additional process colors, such as Orange, Blue or Red (not light inks!), you can select the according patch file.

Example: If you have loaded Cyan, Magenta, Yellow, Black, Gray, Orange, Blue, Red in your printer, chose the BlackAdd_CMYK+3. psd (or _small.psd). Since Gray is a light ink, do not count it as +1 ink.


5.3 Add function

You can add individual charts to print if you would like to test another set of combinations. Be aware that the chart MUST be in multichannel format so you can arrange the channel order in the "Print.." window. We recommend that you put at least 4 spot channels and name then with Cyan, Magenta, Yellow, and Black, so that CW8 can auto-assign them to the proper ink channel.

Note that the multichannel file is a special color mode in Photoshop and may not contain CMYK or RGB color channels on top. Save them in .psd format.

5.4 Print

Print the selected chart for visual analysis. In digital textile printing you should steam and wash the chart since you want to see the final result (as with all charts except with the ink limit charts in most scenarios).



The default charts contain different combinations of black with the other process colors. In the center of each patch you'll find the 100% pure black ink. Around the center is 100% black plus the combination of inks with the values noted aside. If you really find a black that is better outside than inside (better=darker and/or more neutral, etc.) you can use these values to fill them into the "Rich black" fields.

5.5 Rich black

In the example above, the red circled patch has a better black outside than in the center. We will use K100, C60,M60, Y60 for the "Rich black" fields for either Black Addition or GCR.

Note: Do not use extreme combinations, such as K100, C90, M90, Y0, since you might encounter other problems that are not seen in this chart (e.g. light fastness, steaming stability, etc.). We recommend to use a combination containing all values, such as K100, C60, M60, Y30 or K100, C30, M30, Y30, for stability purposes.


Of course, only select a "Rich black" if the combination is really better than the black only, since you will increase the ink amount, leading to higher production costs.

Fill the determined values into the fields. You can only use "Rich black" in combination with Black Addition or Gray Component Replacement method.

6/ Advanced settings

The advanced settings of black generation are provided format experienced users only. Usually, using the regular black generation window will be sufficient to get a high-quality profile. Advanced settings allow to fine-tweak or control certain printing environments, but it can also lead to wrong results if not used properly. Proceed with care and use the default settings, whenever possible.

Here is the window that opens when selecting Advanced settings:



6.1 Revision

By default, CW8 will automatically select the latest color separation technology in the revision list. The latest revision usually delivers the best result for each specific ink combination. We recommend not to change the revision unless specifically instructed by your distributor or by Inèdit.

6.2 Profiling mode

The default profiling mode for neoStampa is RGB profiling. The profiler included in CW8 (optional license) that creates the ICC profile will only work if RGB is selected. In addition to this, all configuration parameters in the black generation will only be available with RGB profiling mode.

CMYK profiles can also be generated. However, CMYK profiles are basic because no parameters of any kind can be selected for their generation- you will notice that most of the options in this window become inactive when this mode is selected.

The black generation using CMYK profiling is usually defined by an external profiler.

6.3 Balance

The "Balance" parameter allows to increase or decrease individual inks to balance the black generation combination using Black Addition or GCR. Since the profiling process will correct irregularities in the balance between inks, the "Balance" option is not really required, and the values should be left at 1.0 In very rare occasions, a certain ink may be much stronger (or weaker), in relation to others, and can be corrected here. The resulting curve will be displayed in the Black generation preview, on the right of the window.

6.4 Black start

The curve control area allows to specify certain conditions on the curve, such as Black start, Body (light) and Body (dark). The Black start sets the start position of the black ink to the defined value.

The default value for Black start using Black Addition is 33%. It means that the additional colors to achieve a richer black will start to enter after 33%, and will reach the specified value at 100%. Below 33% only black ink (including gray) will be used.

The default value for Black start using GCR is 20%. This means that below 20% of black generation, no black ink will be present, but instead it will be replaced with a combination of C, M, and Y inks. This is to prevent dithering of the black ink if no gray ink (=light black inks) is present in the ink set.

6.5 Body (light)

The Body -light- parameter shapes the curve in the lower area of black generation. The ideal value is experimental, but should result in a smooth and regular total curve shape, which can be seen in the Black generation preview.

The default value for Body -light- using Black Addition is 83. The default value fro Body -light- using GCR is 33.

6.6 Body (dark)

The Body -dark- parameter shapes the curve in the upper area of black generation. Also here, the ideal value is experimental and should result in a totally smooth behavior of the final curve as seen in the Black generation preview.

The default value for Body -dark- using Black Addition is 100. The default value for Body (dark) using GCR is 66.

6.7 Ink limit method

neoStampa includes two methods for ink limiting:

Smooth: The default method provides an intelligent ink limiting without clipping behavior in heavy ink load areas. It optimizes the ink amount in extreme areas to provide smoother behavior of gradients but sacrifices 2-3% of gamut.

Clip: The clip method just cuts down the exceeding ink to the defined value. Although the gamut might be 2-3% larger in these extreme areas, it is possible that gradients in very dark areas are not as smooth as with the above method.

6.8 BlackOptimizer®

This function improves the gamut behavior in colorful areas when moving towards saturated, dark colors. Since -specially in digital textile printing-, the regular GCR method doesn't always directly make a color darker, but turns it duller and sometimes even lighter, an intelligent analysis of color-to-dark is required, to improve the combination of colors in the black generation. BlackOptimizer does this analysis based on whether a color is already dark, and therefore uses less GCR to get darker. It is recommended to leave this button always on. If you encounter some dithering from color-to-dark (e.g. if the black ink starts too early), it might help to switch the function off, although it might make the printer gamut less linear.


6.9 Shadow dot gain

A dot gain can be added to improve overprinting of colors, also in darker areas. An insufficient saturation in dark areas is sometimes caused by an intermediate ink limit behavior, which causes a bump between absolute ink limit (2-mix-colors) and the relative ink limit set in the RIP (e.g. 240%). A regular dot gain is usually applied to all colors, but from the CIELab point of view, the linearity is not given anymore. The Shadow dot gain parameter adds a dot gain only where is it required; in already saturated colors, to counteract the bump effect. The default value of 15% is a good balance between improving the bump effect and laying down too much ink, but mainly depends on how heavy the colors have been linearized.

The Early black improves the gradient and linearity from dark-saturated to dark-unsaturated color, affecting the black ink directly in normal cases, and should be switched on by default. Switch it off only if you experience strong jumps in dark-unsaturated areas from the black ink or a rich black combination.


7/ Printer profiling

This is the step in the calibration process where the ICC profile is generated. After completing the hueman v2 black generation window, you will get to the printer profiling one, when hitting next. Remember that this option is only activated if you have purchased the license to generate ICC profiles, so, if you don't have it, the Measure and Generated buttons won't be available, and related options like Smoothing.




7.1 Select target file

In order to print a target for your spectrophotometer, select from the drop-down list the appropriate target: Small/Medium/Large/Very large/Custom. For a high-quality profile, you should print at least 1500 patches for paper prints, and 2250 for textile prints.



Then choose the device from the drop-down list:



7.2 Print


After you have selected the right target, use the "Print..." button to print out the target file on your media. As with all charts, you have to steam and wash it, or have it dry for a couple of minutes (paper printing).

Configure the Print of the target first:



7.3 Measure

You are now ready to measure the target. Make sure you select the same target file that you have previously printed, and click on the "Measure..." button to open the measurement dialog and to connect with the spectrophotometer.



When you finish reading the target, hit Ok to close the measurement dialog and you will see that the "Generate…" button becomes selectable.

7.4 Import data


If you wish to Import a previously stored measurement, you can use the Import button to do so. Note that the CW8 will check whether the data content corresponds to the correct reference file (e.g. amount of patches, etc.).

7.5 Export data

You may need to Export data for example if you'd like to create an ICC profile with an external application such as i1Profiler. CW8 creates CGATS, which are measurement files that are compatible with most ICC profiling software. Select the i1Profiler format if you want to generate the ICC profile with i1Profiler software.

7.6 Smoothing amount

With this option you can specify a certain amount to smooth out error measurements, although much of it is avoided by choosing to do three measurements of each test file, as the CW8 has newly incorporated. Broadly speaking, the more you smooth a profile the less precise this will be, so smoothing should apply only if the global precision of an ICC profile is maintained, and the most important aim is to achieve smoother gradients in printing.



The options for smoothing are, in general terms: **None** should be used when measurements are good, as with paper; **Few** can be selected for stable readings on dense, low-structured textiles; **Normal** would apply with unstable measurements on structured textiles; finally, **High** is only to be selected for extremely structured textiles, like towels. This latter is not recommended to use, as it implies heavy smoothing.

7.7 Generating the profile

After you have measured the target, the "Generate..." button will become available. Select first from all the above parameters and then click on this button to generate de ICC RGB printer profile.

A window will pop up to ask how you'd like to name the profile. It is recommended to give the same name to the profile that you gave to the complete calibration, to avoid confusion. You can also specify where

you'd like to save the generated profile; typically, in the desktop since you can easily distribute if from there, or within your profile folder.


7.8 Add profile to list

Once you have your ICC profile generated, this will appear on the profile list automatically.




7.9 Gamut and quality view

View the linearization and the projection of the profile in the gamut viewer.




If you make a click in the gamut area another window will pop up, showing a color picker with the printable colors. Here you can scroll through the bar to detect errors or smoothness issues coming from irregular measurements or misreadings.



8/Workflow

We have reached the last window of the Calibration.




In the upper part of the window, the Workflow options can be used to define some initial parameters.

Color Preset offers two methods: the Standard mode, which uses the Perceptual mode and thus provides more realistic colors, and ColorBoost, which uses saturated colors and renders brighter colors.



Mirroring is usually used for transfer. In this window you have the option of applying **Full page mirroring**, which will obviously change the whole page.

Input defaults displays a new window:



By default, **Input ICC profiles** is not activated, as changing them may completely change the colors you will print.

The same goes for **Proofing**. This consists of obtaining from our printer the results which would be obtained using another printing system. Please refer to point 5.2 of neoStampa's manual to understand the main rendering intents offered.


Also, beware in the above window if you are going to use the **Design orientation and mirroring** options, because if you have already selected Full page mirroring in the previous window, these buttons will now double the effect.

Full page mirroring and Input defaults provide the same setting options given in the Printer scheme manager, in the Advanced tap.



8.1 Test print

With the **Test print** option you are able to choose a test image and check the profile and print quality.



With the "plus" button you will choose the file you need from your computer. Once selected, this will be included in the drop-down list. To test the image you like, just press **Print**.

8.2 Comments

Quite self-explanatory, an empty area to include **Comments** belonging to the calibration is available.



Those will be seen when you open the Advanced tap of the Printer scheme manager:

8.3 Schemes Backup


In the Printer scheme manager (window above), at the bottom, there are two buttons for you to save copies of the schemes created, generated by the Backup button.



You can name and save your copies, which will be stored as zip files:




Whenever you want to use any of those copies, press Restore and selected it from the given list:



8.4 Finish

The last step will be to "Finish..." the calibration by clicking on this button. You will be prompted to give it a final name to complete the calibration.



Once the wizard is closed, your new calibration will automatically become available in the schemes list, in the Printer scheme manager.

If no other routes have been expressly selected, the usual path is /neoStampa 8/Color/*Printername/Calibration name*. A shortcut to reach this folder is using the Browse... button..



We hope this manual has been useful to you. If you think the contents can be improved in any way, you can send your suggestions to quality@inedit.com

In our web <u>www.inedit.com</u> you will find further support materials such as video tutorials, apart from all the information of the programs and solutions of Inèdit.